

Configuring Gantt Columns



Columns shown in the left frame of the Gantt chart may be selectively hidden from the view. The following procedure describes how to configure the visibility of these columns.



1. With the Gantt chart window open, right-click on a column heading to display the context menu:

Note: All columns are checked by default.

	Activity/Resource	Duration	Begin Ti	End Tim	
	Alt Line	80.000	0.000	80.000	
	Station 1_1	20.000	0.000	20.000	
	Resource 1	20.000	0.000	20.000	
	BIWActivityLoading.1	5.000	0.000	5.000	
	BIWActivitySpotWelding.1	10.000	5.000	15.000	
	BIWActivityUnLoading.1	5.000	15.000	20.000	
	Station 2_1	40.000	20.000	60.000	
	Resource 2	40.000	20.000	60.000	
	BIWActivityLoading.1	10.000	20.000	30.000	
	BIWActivitySpotWelding.1	20.000	30.000	50.000	

Show All Columns

Hide All Columns

Activity/Resource

Duration [s]

Begin Time [s]

End Time [s]

Number Of Point Fasteners

Length Of Curve Fastener (m)

Resource

Description

2. Deselect all columns except Begin Time, End Time and Duration.

	Activity/Resource	Duration	Begin Ti	End Tim	
	Alt Line	80.000	0.000	80.000	
	Station 1_1	20.000	0.000	20.000	
	Resource 1	20.000	0.000	20.000	
	BIWActivityLoading.1	5.000	0.000	5.000	
	BIWActivitySpotWelding.1	10.000	5.000	15.000	
	BIWActivityUnLoading.1	5.000	15.000	20.000	
	Station 2_1	40.000	20.000	60.000	
	Resource 2	40.000	20.000	60.000	
	BIWActivityLoading.1	10.000	20.000	30.000	
	BIWActivitySpotWelding.1	20.000	30.000	50.000	

Show All Columns

Hide All Columns

Activity/Resource

Duration [s]

Begin Time [s]

End Time [s]

Number Of Point Fasteners

Length Of Curve Fastener (m)

Resource

Description

3. Select Hide All Columns.

Activity/Resource		
	Alt Line	
	Station 1_1	
	Resource 1	
	BIWActivityLoading.1	
	BIWActivitySpotWelding.1	
	BIWActivityUnLoading.1	
	Station 2_1	
	Resource 2	
	BIWActivityLoading.1	
	BIWActivitySpotWelding.1	

☒ Show All Columns
☐ Hide All Columns
☒ Activity/Resource
☐ Duration [s]
☐ Begin Time [s]
☐ End Time [s]
☐ Number Of Point Fasteners
☐ Length Of Curve Fastener (m)
☐ Resource
☐ Description

To re-display all the columns, select Show All Columns.

