

# Changing the Transparency of the Surfaces



To change the transparency of the surfaces, manipulate the **Transparency** slider in the **Surface Color** section of the **Properties** dialog box.

Moving the slider to a value greater than 0 (zero) activates the transparency for the selected surfaces. The greater the value, the more transparent the surface becomes. Transparency values range from 0 to 255.

