

# IBM Storage FlashSystem® 5045 Installation Poster



Before installing the IBM Storage FlashSystem 5045 read the **IBM Systems Safety Notices** in the publications package.



Online Notices



How to

1. Get an IBM ID
2. Register the product
3. Subscribe for alerts
4. View IBM Documentation
5. Open a ticket
6. Get new code versions


## 1 Preparing for setup



Planning Worksheet




Phillips Screwdriver




Ethernet Cable




Ethernet, DHCP



Power




Network







Rack Space

## 2 Verify the enclosure packages

### \* Control enclosure






Hardware kit contains extra screws and pins for various rack types.










### Expansion enclosure

Optional

Hardware kit contains extra screws and pins for various rack types.




## 3 Install enclosures




# IBM Storage FlashSystem® 5045 Installation Poster

## ④ Connect cables



## ⑤ Power on



## ⑥ Set up the system



(1P) P/N: 03LG796

