

IBM Storwize V7000 Unified
Version 1.3
Machine Types 2073-700 and 2076

Problem Determination Guide - Errata



Contents

Introduction	v	Chapter 4. File module	1
------------------------	---	----------------------------------	---

Introduction

This guide provides errata information that pertains to release 1.3.0 of the *IBM® Storwize® V7000 Unified Problem Determination Guide*.

Who should use this guide

This errata should be used by anyone using the *Problem Determination Guide*. You should review the errata that is contained within this guide and note the details with respect to the copy of the *Problem Determination Guide* that was downloaded to your system.

Last update

This document was last updated on January 9, 2012.

Change history

The following revisions have been made to this document:

Table 1. Change history

Revision date	Sections modified
December 22, 2011	New publication
January 9, 2012	Removing a hot-swap ac power supply

Chapter 4. File module

From the *Problem Determination Guide*, follow the table of contents sequence to view *File module* in Chapter 4.

Removing a hot-swap ac power supply

Page 131. The following information should be removed:

Important: The file module has two power supplies for redundancy. Do not replace a power supply while the file module is powered on. Both power supplies are required to provide redundancy to the file module. Follow the procedures in *Powering off your system to power off the file module before replacing a power supply* on page 202 to power off the file module before replacing a power supply.

The following correction replaces the above information:

Important: The file module has two power supplies for redundancy. Do not replace a power supply while the file module is powered on. Both power supplies are required to provide redundancy to the file module. Follow the procedures in *Removing a file module to perform a maintenance action* on page 47 to power off the file module before replacing a power supply.



Printed in USA